

Tri-Band Radio Unit Hardware Training

Duration

eLearning: Self-paced

Contents

This course trains students on the capabilities of the Tri-band radio and installation procedures to allow a successful installation into a 5G wireless network. Procedures include hardware mounting and cable installation tutorials specific to this Radio Unit (RU).

Who Should Attend

This course is for anyone needing to understand the capabilities of the Radio Unit hardware and the installation needs and recommendations. This includes: tower installation technicians, cell site technicians, site commissioning teams, managers of installation and commissioning teams, RF planning engineers, and network planning engineers.

Outline

- Overview
 - O-RAN Capability
 - RU Antenna Connectors
 - Bands and Carriers
 - Narrowband IoT
 - Tri-Band RU Hardware
 - Capabilities of RU - Band 71
 - Capabilities of RU - Band 29
 - Capabilities of RU - Band 26
 - RU Common Operating Specifications
 - RU DC Power Specifications
 - RU Dimensions
- Tri-Band Hardware
 - Installation Precautions
 - Installation Tools
 - Installation Checklists
 - Mounting Kit Parts
 - Unpacking
 - L-Brackets and Hardware
 - Wall Plate and Adapter with Hardware
 - L-Brackets and Hardware
 - Exploded View of Mounting Hardware
 - RU Mounting Brackets
 - Wall Mounting
 - Wall Mount Plate
 - RU Attachment to Wall Plate
 - Pole Mount – Clamp Tube A
 - Pole Mount – Clamp Tube B
 - Mount Assembly to Plate
 - Secure RU Assembly to Plate
 - Test Fit of Assembly
 - Torque Specifications for Mounting Hardware
- Tri-Band RU Hardware - Cable and Connector Installation
 - Ground Connection
 - Ground Lug Location on RU
 - Installing Optical SFP
 - Fiber Cabling Connectors
 - Remove Protective Covers
 - Remove Caps and Pull Back Sub-Assembly
 - Insert Optical Cables into SFP
 - Connecting Optical Cable Assembly
 - Lock Enclosure
 - Mate Protective Covers
 - Installing AISG RET Cables
 - Installing DC Power Cables
 - Installing RF Cables
 - Torque Specs and Wrench – 4.3-10 Connectors
- LED Indicators
 - RU LED Location
 - RU LED
- Troubleshooting
 - Critical Alarms
 - Major Alarms
 - Minor Alarms
 - Full Alarm List
- Removal and Return Procedures
 - Removal Process
 - Returning Defective Equipment
- Appendix A
 - References
- Appendix B - Zero Touch Provisioning
 - ZTP Overview for RU
 - ZTP- Locating Management Server
 - ZTP – Configuring Fault and Configuration Servers
 - ZTP – Configuring DU and RU
 - 3GPP-Based Auto Commissioning Flow
- Appendix C - SFP List
 - SFP Candidate List
- Appendix D
 - Standard Weatherproofing Procedure
- Appendix E
 - Documentation References